


SINGLE PHASE ELECTRIC

ENERGY METER





PRODUCT SIZE



Voltage incoming

TECHNICAL PARAMETER





APPLICATION



22

В


21

17

RS485 ACTIVE ENERGY


18

N' N



LOAD


10 (80) A Wiring











press the key to chang the page

after setting up press


press are to enter the setting page you want by using 🙀 😻 to set the parameters

.CL,E

≈c o d E 000 1

3. PUSH UP THE BUCKLE

OPERATION DIAGRAM



4.THE METER CAN BE FIXED





It cannot communicate with the host computer normally after the instrument

1. The voltage value between the communication output A and B of the measuring

connected with Corresponding to communication serial port A/B);

2. Check whether the communication wiring method is correctly wired according to the wiring diagram (that is, the communication terminal A/B of the instrument must be

POWER DISTRIBUTOR ROOM

BUILDING



powered on.

APPLICATION

MALL AND SUPERMARKET

instrument should be between +(4.4-4.5)V.



SCHOOL





Acrel Co., Ltd. [Stock Code: 300286. SZ] is a high-tech enterprise concentrating on